



Data Sheet 2.16

Issue A



Vane Type Waterflow Alarm Switch with Retard

Model RDVSR (EU)

ΔΙΑΚΟΠΤΕΣ ΡΟΗΣ ΜΕ ΧΡΟΝΙΚΗ ΥΣΤΕΡΗΣΗ

Product Description

The Model RDVSR-EU is a vane type waterflow switch for use on wet sprinkler systems. It is UL Listed and FM Approved for use on steel pipe; schedules 10 through 40, sizes 50 mm thru 200 mm (2" thru 8"). LPC approved sizes are 50 mm thru 200 mm (2" thru 8").

The RDVSR-EU may also be used as a sectional waterflow detector on large systems. The RDVSR-EU contains two single pole, double throw, snap action switches and an adjustable, instantly recycling pneumatic retard. The switches are actuated when a flow of 38 LPM (10 GPM) or more occurs downstream of the device. The flow condition must exist for a period of time necessary to overcome the selected retard period.

Enclosure

The RDVSR-EU switches and retard device are enclosed in a general purpose, die-cast housing. The cover is held in place with two tamper resistant screws which require a special key for removal.

Warning

- Installation must be performed by qualified personnel and in accordance with all national and local codes and ordinances.
- Shock hazard. Disconnect power source before servicing. Serious injury or death could result.
- Risk of explosion. Not for use in hazardous locations. Serious injury or death could result.

Caution

Waterflow switches that are monitoring wet pipe sprinkler systems shall not be used as the sole initiating device to discharge AFFF, deluge, or chemical suppression systems. Waterflow switches used for this application may result in unintended discharges caused by surges, trapped air, or short retard times.

Ordering Codes

Nominal Pipe Size		Ordering Codes
DN50	2"	RDVSR-EU50
DN65	2 1/2"	RDVSR-EU65
DN80	3"	RDVSR-EU80
DN100	4"	RDVSR-EU100
DN125	5"	RDVSR-EU125
DN150	6"	RDVSR-EU150
DN200	8"	RDVSR-EU200



Technical Details

Working Pressure	UL & FM - 31 bar (450 psi) VdS & LPCB - 16 bar (230 psi)
Flow Sensitivity Range for Signal	15-38 LPM (4-10 GPM) - UL 30-57 LPM (8-15 GPM) - VdS No Signal below 1 LPM (2.6 GPM) - VdS
Pressure Loss	0.2 bar (3 psi) max. at 5 m/s (DN50-100) 0.07 bar (1 psi) max. at 5 m/s (DN150-200)
Maximum Surge	5.5 m/s (18 FPS)
Contact Ratings	Two sets of SPDT (Form C) 10.0 Amps at 125/250 VAC 2.0 Amps at 30VDC Resistive 10 mAmps min. at 24 VDC
Conduit Entrances	Two knockouts provided for 1/2" conduit.
Environmental Specification	<ul style="list-style-type: none"> • NEMA 4/IP54 Rated Enclosure suitable for indoor or outdoor use with factory installed gasket and die-cast housing when used with appropriate conduit fitting. • Temperature Range: 4.5°C - 49°C (40°F - 120°F) - UL 1°C - 68°C (34°F - 154°F) - VdS • Non-corrosive sleeve factory installed in saddle.
Service Use	Automatic Sprinkler - NFPA-13 One or two family dwelling - NFPA-13D Residential occupancy up to four stories - NFPA-13R National Fire Alarm Code - NFPA-72

Manufactured by Potter who hold FM Approval, UL Listing, LPCB, VdS and CE Certificates

DS: 2.16
Issue A
23/02/2021
© 2021 Rapidrop

Rapidrop Global Ltd



Data Sheet 2.16

Issue A



Vane Type Waterflow Alarm Switch with Retard

Model RDVSR (EU)

Installation

These devices may be mounted on horizontal or vertical pipe. On horizontal pipe they shall be installed on the top side of the pipe where they will be accessible. The device should not be installed within 15 cm (6") of a fitting which changes the direction of the waterflow or within 60 cm (24") of a valve or drain.

NOTE: Do not leave cover off for an extended period of time.

Drain the system and drill a hole in the pipe using a hole saw in a slow speed drill (see Fig. 1). Clean the inside pipe of all growth or other material for a distance equal to the pipe diameter on either side of the hole. Roll the vane so that it may be inserted into the hole; do not bend or crease it. Insert the vane so that the arrow on the saddle points in the direction of the waterflow. Take care not to damage the non-corrosive bushing in the saddle. The bushing should fit inside the hole in the pipe. Install the saddle strap and tighten nuts alternately to required torque (see the chart in Fig. 1). The vane must not rub the inside of the pipe or bind in any way.




Fig. 1

Caution

Do not trim the paddle. Failure to follow these instructions may prevent the device from operating and will void the warranty.

Do not obstruct or otherwise prevent the trip stem of the flow switch from moving when water flows as this could damage the flow switch and prevent an alarm. If an alarm is not desired, a qualified technician should disable the alarm system.


Caution

Hole must be drilled perpendicular to the pipe and vertically centred. Refer to the Compatible Pipe/Installation Requirements chart for size.



Retard Adjustment

The delay can be adjusted by rotating the retard adjustment knob from 0 to the max setting (20-30 seconds). The time delay should be set at the minimum required to prevent false alarms.



USE (2) 5180162 ADAPTERS AS SHOWN ABOVE

Compatible Pipe / Installation Requirements

Nominal Pipe Size		Nominal Pipe O.D		Pipe Wall Thickness								Hole Size		U-Bolt Nuts Torque	
				Schedule 10 (UL)		Schedule 40 (UL)		BS-1387 (LPC)		DN (VdS)					
mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	NM	ft=lb
DN 50	2"	60.3	2.375	2.77	0.109	3.91	0.154	3.6	0.142	2.3	0.091	33.0 ± 2	1.25 + 0.125 / -0.062	27	20
DN 65	2 1/2"	73.0	2.875	3.05	0.120	5.16	0.203	-	-	-	-	33.0 ± 2	1.25 + 0.125 / -0.062	27	20
DN 65	2 1/2"	76.1	3.000	-	-	-	-	3.6	0.142	2.6	0.102	33.0 ± 2	1.25 + 0.125 / -0.062	27	20
DN 80	3"	88.9	3.500	3.05	0.120	5.49	0.216	4.0	0.157	2.9	0.157	50.8 ± 2	2.00 ± 0.125	27	20
DN 100	4"	114.3	4.500	3.05	0.120	6.02	0.237	4.5	0.177	3.2	0.125	50.8 ± 2	2.00 ± 0.125	27	20
DN 125	5"	139.7	5.500	-	-	-	-	5.0	0.197	3.6	0.142	50.8 ± 2	2.00 ± 0.125	27	20
DN 125	5"	141.3	5.563	3.40	0.134	6.55	0.258	-	-	-	-	50.8 ± 2	2.00 ± 0.125	27	20
DN 150	6"	168.3	6.625	3.40	0.134	7.11	0.280	5.0	0.197	4.0	0.157	50.8 ± 2	2.00 ± 0.125	27	20
DN 200	8"	219.1	8.625	3.76	0.148	8.18	0.322	6.3	0.248	4.5	0.177	50.8 ± 2	2.00 ± 0.125	27	20

Manufactured by Potter who hold FM Approval, UL Listing, LPCB, VdS and CE Certificates

DS: 2.16
Issue A
23/02/2021
© 2021 Rapidrop

Rapidrop Global Ltd



Data Sheet 2.16

Issue A



Vane Type Waterflow Alarm Switch with Retard

Model RDVSR (EU)



Testing

The frequency of inspection and testing for the Model RDVSR-EU and its associated protective monitoring system shall be in accordance with applicable NFPA Codes and Standards and/or the authority having jurisdiction (manufacturer recommends quarterly or more frequently).

If provided, the inspector's test valve shall always be used for test purposes. If there are no provisions for testing the operation of the flow detection device on the system, application of the RDVSR-EU is not recommended or advisable. A minimum flow of 38 LPM (10 GPM) is required to activate this device.

Note: Advise the person responsible for testing of the fire protection system that this system must be tested in accordance with the testing instructions.

Fig. 5 Mounting Dimensions



NOMINAL PIPE DIA. +44.5 mm (+1.75 in) FOR DN 50 – DN 65 2–2.5 in
NOMINAL PIPE DIA. +54.0 mm (+2.125 in) FOR DN 80 – DN 200 3–8 in


Maintenance

Inspect detectors monthly. If leaks are found, replace the detector. The RDVSR-EU waterflow switch should provide years of trouble-free service. The retard and switch assembly are easily field replaceable. In the unlikely event that either component does not perform properly, please order replacement retard switch assembly stock #1029020 (see Fig. 7). There is no maintenance required, only periodic testing and inspection.

Removal of Waterflow Switch

- To prevent accidental water damage, all control valves should be shut tight and the system completely drained before waterflow detectors are removed or replaced.
- Turn off electrical power to the detector, then disconnect wiring.
- Loosen nuts and remove U-bolts.
- Gently lift the saddle far enough to get your fingers under it. With your fingers, roll the vane so it will fit through the hole while continuing to lift the waterflow detector saddle.
- Lift detector clear of pipe.

Fig. 6



Manufactured by Potter who hold FM Approval, UL Listing, LPCB, VdS and CE Certificates

DS: 2.16
Issue A
23/02/2021
© 2021 Rapidrop

Rapidrop Global Ltd




Vane Type Waterflow Alarm Switch with Retard Model RDVSR (EU)

Retard/Switch Assembly Replacement

Note: The Retard/Switch Assembly is field-replaceable without draining the system removing or removing the waterflow switch from the pipe

1. Make sure the fire alarm zone or circuit connected to the waterflow switch is bypassed or otherwise taken out of service.
2. Disconnect the power source for local bell (if applicable).
3. Identify and remove all wires from the waterflow switch.
4. Remove the (2) mounting screws holding retard/switch assembly to the base. Do not remove the (2) retard housing screws.
5. Remove the retard assembly by lifting it straight up over the tripstem.
6. Install the new retard assembly. Make sure the locating pins on the retard/switch assembly fit into the locating pin bosses on the base.
7. Re-install the (2) original mounting screws.
8. Reconnect all wires. Perform a flow test and place the system back in service.

Fig. 7



Manufactured by Potter who hold FM Approval, UL Listing, LPCB, VdS and CE Certificates

DS: 2.16
Issue A
23/02/2021
© 2021 Rapidrop

Rapidrop Global Ltd